


Carbon Fiber Selfie Stick


偏心管碳纤维自拍杆



- 1 Twist the bar counterclockwise to unlock the eccentric tube, at which point the selfie stick can be retracted.
逆时针拧动杆身，即可解锁偏心管，此时可伸缩自拍杆。
- 2 Twist the bar clockwise to lock the eccentric tube, at which point the length of the selfie bar can be fixed.
顺时针拧动杆身，即可锁紧偏心管，此时可固定自拍杆的长度。
- 3 When recovering the selfie stick, twist the rod clockwise to lock the eccentric tube to prevent the selfie stick from stretching at will.
回收自拍杆时，顺时针拧动杆身锁紧偏心管，以防止自拍杆随意伸缩。

adapter head can be transferred to sports cameras and cell phone clips, but also can be transferred to a variety of desired shooting equipment.

转接云台可转接运动相机和手机夹，还可以转接各种想要的拍摄设备。



Disclaimer 免责声明

Please read this statement carefully and by using this product you will be deemed to have acknowledged and accepted it in full. Please check the product carefully before each use and do not use it if damaged or deformed. By using this product, you acknowledge and agree that you are fully responsible for your actions and the possible consequences of using this product. You undertake to use this product only for legitimate and lawful purposes. You understand and agree that ("Telesin") shall not be liable for any misuse, adverse effects, damages, injuries, penalties or other legal consequences arising directly or indirectly from the use of this product. The user should follow the precautions including but not limited to those mentioned herein. To the extent Telesin reserves the right to interpret and modify this commitment within the limits of national laws and regulations.

请仔细阅读本声明，一旦使用本产品，即视为对本声明的全部认可和接受。每次使用前，请仔细检查产品，若出现破损、变形，请勿使用。使用本产品，就意味着您认可并同意，您将对使用本产品的行为和可能产生的后果负全部责任。您承诺仅会出于正当合法的目的使用本产品。您理解并同意，对于直接或间接因使用本产品而造成的滥用、不利影响、损害、伤害、惩罚或者其他法律后果，泰迅数码有限公司（以下简称“Telesin”）将不承担任何责任。用户应遵循包括但不限于本文提及的使用注意事项。在国家法律法规范围内，本承诺解释权、修改权归 Telesin 所有。